


Installation and Operation Instructions EVE-OG-25 – 40 F



Owner's manual was created in the German language.
Please retain for future use!



Inhaltsverzeichnis

1. Preface	2
2. Technical Data	2
3. Product Description	3
Use	3
Principle of Operation.....	3
Oil Circulation.....	3
Cooling.....	4
Start Controls	4
4. Safety	4
Intended Use.....	4
Safety Notes	4
Emission of Oil Mist.....	4
Noise Emission	5
5. Transport	5
Transport in Packaging	5
Transport without Packaging	5
6. Storage	5
Short-term Storage.....	5
Conservation	5
7. Installation and Commissioning	6
Installation Prerequisites	6
Mounting Position and Space	6
Suction Connection.....	6
Gas Discharge.....	6
Installation.....	7
Mounting.....	7
Connecting Electrically.....	7
Connection Scheme Three-Phase Motor	7
Connecting Lines/Pipes	7
Filling Oil.....	8
Recording of Operational Parameters	8
Operation Notes	8
Use.....	8
Oil Return	9
Conveying Condensable Vapours.....	9
8. Maintenance	9
8.1 Maintenance Schedule	9
Checking the Oil.....	10
Checking the Level	10
Topping up Oil	10
Checking the Colour of the Oil	10
Oil Life.....	10
Oil and Oil Filter Change	10
Draining Used Oil.....	10
Flushing the Vacuum Pump.....	11
Replacing the Oil Filter.....	11
Filling in Fresh Oil.....	11
Exhaust Filter	11
Checks during Operation	11
Assessment.....	12
Change of the Exhaust Filter.....	12
Removing the Exhaust Filter	12
Inserting the Exhaust Filter	12
9. Overhaul	12
10. Removal from Service	13
Temporary Removal from Service	13
Recommissioning	13
Dismantling and Disposal.....	13
11. Troubleshooting	14
12. Exploded View	19
13. Spare Parts	20
14. Spare Parts Kits	21
15. Accessories	21
16. Oil	22
17. EC-Declaration of Conformity	23
17. Schmalz world wide	24

1. Preface

Congratulations on your purchase of the Schmalz vacuum pump. With watchful observation of the field's requirements, innovation and steady development Schmalz delivers modern vacuum and pressure solutions worldwide.

These operating instructions contain information for

- product description,
 - safety,
 - transport,
 - storage,
 - installation and commissioning,
 - maintenance,
 - overhaul,
 - troubleshooting and
 - spare parts
- of the vacuum pump.


For the purpose of these instructions, "handling" the vacuum pump means the transport, storage, installation, commissioning, influence on operating conditions, maintenance, troubleshooting and overhaul of the vacuum pump.

Prior to handling the vacuum pump these operating instructions shall be read and understood. If anything remains to be clarified please contact your Schmalz representative!

Keep these operating instructions and, if applicable, other pertinent operating instructions available on site.

2. Technical Data

Nominal suction capacity (50Hz/60Hz)	m ³ /h	EVE-OG-25 F: 25/30 EVE-OG-40 F: 40/48
Suction capacity at 1 mbar (50Hz/60Hz)	m ³ /h	EVE-OG-25 F: 23/27 EVE-OG-40 F: 35/41
Ultimate pressure abs.	hPa (=mbar)	0,1
Motor nominal rating (50Hz/60Hz)	kW	EVE-OG-25 F: 1,0/1,2 EVE-OG-40 F: 1,4/1,7
Motor nominal speed (50Hz/60Hz)	min ⁻¹	1500/1800
Sound pressure level (ISO 2151) (50Hz/60Hz)	dB (A)	EVE-OG-25 F: 60/63 EVE-OG-40 F: 63/66
Water vapour tolerance max.	hPa (=mbar)	40
Water vapour capacity	l/h	EVE-OG-25 F: 0,9 EVE-OG-40 F: 1,1
Operating temperature (50Hz/60Hz)	°C	EVE-OG-25 F: 80/85 EVE-OG-40 F: 82/90
Ambient temperature range	°C	see „Oil“
Ambient pressure		Atmospheric pressure
Oil quantity	l	1,0
Weight approx. (50Hz/60Hz)	kg	EVE-OG-25 F: 36 EVE-OG-40 F: 42



3. Product Description

Use

The vacuum pump is intended for the suction of air and other dry, non-aggressive, non-toxic and non-explosive Gases.

Conveying media with a lower or higher density than air leads to an increased thermal and/or mechanical load on the vacuum pump and is permissible only after prior consultation with Schmalz.

Permissible temperature range of the inlet gas: see "Oil", "Ambient temperature range"

In case the vacuum pump is equipped with a gas ballast (optional) water vapour within the gas flow can be tolerated within certain limits (→ page 9: Conveying Condensable Vapours). The conveyance of other vapours shall be agreed upon with Schmalz.

The vacuum pump is intended for the placement in a non-potentially explosive environment.

Version with float valve (j, 200) and oil return line:

The vacuum pump is thermally suitable for continuous operation (100 percent duty).

Version with oil return valve (f, 280):

The vacuum pump is thermally suitable for continuous operation (observe the notes with regard to the oil recirculation: → page 4: Oil Circulation; → page 9: Oil Return).

The vacuum pump is ultimate pressure proof.

Principle of Operation

The vacuum pump works on the rotating vane principle.

A circular rotor (s, 14) is positioned centrally on the shaft of the vacuum pump. The shaft of the vacuum pump is driven by the drive motor shaft by means of a flexible coupling (310).

The rotor (s, 14) rotates in an also circular, fixed cylinder (t, 1), the centreline of which is offset from the centreline of the rotor such that the rotor and the inner wall of the cylinder almost touch along a line.

Vanes (r, 22), sliding in slots in the rotor, separate the space between the rotor and the cylinder into chambers. At any time gas is sucked in and at almost any time ejected. Therefore the vacuum pump works almost pulsation free.

In order to avoid the suction of solids, the vacuum pump is equipped with a screen (261) in the suction connection.

In order to avoid reverse rotation after switching off, the vacuum pump is equipped with a non-return valve (257).

Note: This valve shall not be used as a non-return valve or shut-off valve to the vacuum system and is no reliable means to prevent suction of oil into the vacuum system while the vacuum pump is shut down.

In case the vacuum pump is equipped with a gas ballast (optional):

Through the gas ballast (440) a small amount of ambient air is sucked into the pump chamber and compressed together with the process gas. This counteracts the accumulation of condensates from the process gas inside the vacuum pump (→ page 9: Conveying Condensable Vapours).

The gas ballast line is equipped with a sinter metal filter.

Gas ballast version with ball valve:

The gas ballast line can be closed partially or completely by means of a ball valve.

In order to improve the operating characteristics the outlet of the pump chamber is equipped with a spring loaded valve (q, 159).

Oil Circulation

The vacuum pump requires oil to seal the gaps, to lubricate the vanes (r, 22) and to carry away compression heat.

The oil reservoir is located on the pressure side of the vacuum pump (i.e. high pressure) at the bottom of the bottom chamber of the oil separator (o, 75).

The feed openings are located on the suction side of the vacuum pump (i.e. low pressure).

Forced by the pressure difference between pressure side and suction side oil is being drawn from the oil separator (o, 75) through the oil supply lines (210) and injected on the suction side.

Together with the sucked gas the injected oil gets conveyed through the vacuum pump and ejected into the oil separator (o, 75) as oil mist.
Oil that separates before the exhaust filter (p, 120) accumulates at the bottom of the bottom chamber of the oil separator (o, 75).

Oil that is separated by the exhaust filter (p, 120) accumulates at the bottom of the upper chamber of the oil separator (o, 75).

The flow resistance of the exhaust filters (p, 120) causes the inside of the exhaust filters (which is connected to the bottom chamber of the oil separator) to be on a higher pressure level than the outside of the exhaust filters (i.e. the upper chamber of the oil separator). Because of the higher pressure in the bottom chamber it is not possible to let oil that drips off the exhaust filters simply flow down to the bottom chamber.

Version with float valve and oil return line to the suction connection (j, 200):

Therefore the oil that accumulates in the upper chamber is sucked through the float valve (j, 200) and the oil return line (j, 195) to the suction connection (250).

Version with oil return valve (f, 280):

At continuous operation this would cause the entire supply of oil to accumulate at the bottom of the upper chamber, expel oil droplets through the gas discharge/pressure connection and let the vacuum pump run dry. Therefore the vacuum pump must be shut down at the latest after 10 hours of continuous operation, depending on the operating conditions even after a shorter period, for at least approx. 15 minutes (➔ page 8: Operation Notes). After turning off the vacuum pump the pressure difference between the inside and the outside of the exhaust filter(s) (p, 120) collapses, hence the two chambers of the oil separator assume an equal pressure level, the oil return valve (f, 280) between the two chambers opens and the accumulated oil in the upper chamber can run down to the bottom chamber.

Cooling

The vacuum pump is cooled by

- radiation of heat from the surface of the vacuum pump incl. oil separator (o, 75)
- the air flow from the fan wheel of the drive motor (400)
- the process gas
- the air flow from the fan wheel (e, 321) on the shaft of the vacuum pump

Start Controls

The vacuum pump comes without start controls. The control of the vacuum pump is to be provided in the course of installation.

4. Safety

Intended Use

Definition: For the purpose of these instructions, "handling" the vacuum pump means the transport, storage, installation, commissioning, influence on operating conditions, maintenance, troubleshooting and overhaul of the vacuum pump.
The vacuum pump is intended for industrial use. It shall be handled only by qualified personnel.

The allowed media and operational limits (➔ page 3: Product Description) and the installation prerequisites (➔ page 6: Installation Prerequisites) of the vacuum pump shall be observed both by the manufacturer of the machinery into which the vacuum pump is to be incorporated and by the operator.

The maintenance instructions shall be observed.
Prior to handling the vacuum pump these installation and operating instructions shall be read and understood. If anything remains to be clarified please contact your Schmalz representative!

Safety Notes

The vacuum pump has been designed and manufactured according to state-of-the-art methods. Nevertheless, residual risks may remain.
These operating instructions highlight potential hazards where appropriate. Safety notes are tagged with one of the keywords **DANGER**, **WARNING** and **CAUTION** as follows:



DANGER

Disregard of this safety note will always lead to accidents with fatal or serious injuries.



WARNING

Disregard of this safety note may lead to accidents with fatal or serious injuries.



CAUTION

Disregard of this safety note may lead to accidents with minor injuries or property damage.

Emission of Oil Mist



CAUTION

The non-OEM spares market offers exhaust filters that are geometrically compatible with Schmalz-vacuum-pumps, but do not feature the high retention capacity of genuine Schmalz-exhaust filters.

Increased risk of damage to health.

In order to keep the emission on the lowest possible level only genuine Schmalz-exhaust filters shall be used.

The oil in the process gas is separated to the greatest possible extent, but not perfectly.



CAUTION

The gas conveyed by the vacuum pump contains remainders of oil.

Aspiration of process gas over extended periods can be harmful.

The Room into which the process gas is discharged must be sufficiently vented.

Note: The possibly sensible smell is not caused by droplets of oil, though, but either by gaseous process components or by readily volatile and thus gaseous components of the oil (particularly additives).

Noise Emission

For the sound pressure level in free field according to EN ISO 2151 → page 2: Technical Data.

5. Transport

Note: Also a vacuum pump, that is not topped up with oil contains residues of oil (from the test run). Always transport and store the vacuum pump in upright position. Do not put the vacuum pump on its side or put it upside down.

Transport in Packaging

Packed on a pallet the vacuum pump is to be transported with a forklift.

Transport without Packaging

In case the vacuum pump is packed in a cardboard box with inflated cushions:

- Remove the inflated cushions from the box

In case the vacuum pump is in a cardboard box cushioned with rolled corrugated cardboard:

- Remove the corrugated cardboard from the box

In case the vacuum pump is laid in foam:

- Remove the foam

In case the vacuum pump is bolted to a pallet or a base plate:

- Remove the bolting between the vacuum pump and the pallet/ base plate

In case the vacuum pump is fastened to the pallet by means of tightening straps:

- Remove the tightening straps



CAUTION

Do not walk, stand or walk under suspended loads.

- Make sure that the eyebolt (k, 391) is in faultless condition (replace a damaged, e.g. bent eyebolt with a new one)
- Make sure that the eyebolt (k, 391) is fully screwed in and tightened by hand
- Attach lifting gear securely to the eyebolt (k, 391) on the oil separator
- Attach the lifting gear to a crane hook with safety latch
- Lift the vacuum pump with a crane

In case the vacuum pump was bolted to a pallet or a base plate:

- Remove the stud bolts from the rubber feet



CAUTION

Tilting a vacuum pump that is already filled with oil can cause large quantities of oil to ingress into the cylinder.

Starting the vacuum pump with excessive quantities of oil in the cylinder will immediately brake the vanes (r, 22) and ruin the vacuum pump.

Once the vacuum pump is filled with oil it shall not be lifted anymore.

- Prior to every transport make sure that the oil is drained

6. Storage

Short-term Storage

Version with gas ballast with ball-valve:

- Make sure that the ball-valve of the gas ballast device (440) is closed

Version with gas ballast without ball-valve, with sinter metal filter:

- Close the sinter metal filter of the gas ballast device (440) with adhesive tape
- Make sure that the suction connection and the gas discharge are closed (leave the provided plugs in)
- Store the vacuum pump
 - if possible in original packaging,
 - indoors,
 - dry,
 - dust free and
 - vibration free

Conservation

In case of adverse ambient conditions (e.g. aggressive atmosphere, frequent temperature changes) conserve the vacuum pump immediately. In case of favourable ambient conditions conserve the vacuum pump if a storage of more than 3 months is scheduled.

During the test run in the factory the inside of the vacuum pump was completely wetted with oil. Under normal conditions a treatment with conservation oil is therefore not required. In case it is advisable to treat the vacuum pump with conservation oil because of very adverse storage conditions, seek advice from your Schmalz representative!

Version with gas ballast with ball-valve:

- Make sure that the ball-valve of the gas ballast (440) is closed

Version with gas ballast without ball-valve, with sinter metal filter:

- Close the sinter metal filter of the gas ballast (440) with adhesive tape
- Make sure that all ports are firmly closed; seal all ports that are not sealed with PTFE-tape, gaskets or o-rings with adhesive tape

Note: VCI stands for "volatile corrosion inhibitor". VCI-products (film, paper, cardboard, foam) evaporate a substance that condenses in molecular thickness on the packed good and by its electro-chemical properties effectively suppresses corrosion on metallic surfaces. However, VCI-products may attack the surfaces of plastics and elastomers. Seek advice from your local packaging dealer! Schmalz uses CORTEC VCI 126 R film for the overseas packaging of large equipment.

- Wrap the vacuum pump in VCI film
- Store the vacuum pump
 - if possible in original packing,
 - indoors,
 - dry,
 - dust free and
 - vibration free.

For commissioning after conservation:

- Make sure that all remains of adhesive tape are removed from the ports
- Commission the vacuum pump as described in the chapter Installation and Commissioning (→page 6)

7. Installation and Commissioning

Installation Prerequisites



CAUTION

In case of non-compliance with the installation prerequisites, particularly in case of insufficient cooling.

Risk of damage or destruction of the vacuum pump and adjoining plant components!

Risk of injury!

The installation prerequisites must be complied with.

- Make sure that the integration of the vacuum pump is carried out such that the essential safety requirements of the Machine Directive 2006/42/EC are complied with (in the responsibility of the designer of the machinery into which the vacuum pump is to be incorporated; ➔ page 24: note in the EC-Declaration of Conformity)

Mounting Position and Space

- Make sure that the environment of the vacuum pump is not potentially explosive
- Make sure that the following ambient conditions will be complied with:
- ambient temperature: see "Oil"
If the vacuum pump is installed in a colder environment than allowed with the oil used:
 - Fit the vacuum pump either with an oil sump heating (on request)
or
fit the vacuum pump with a temperature switch and control the vacuum pump such that it will start automatically when the oil sump temperature falls below the allowed temperature
- ambient pressure: atmospheric
- Make sure that the environmental conditions comply with the protection class of the drive motor (according to the nameplate)
- Make sure that the vacuum pump will be placed or mounted horizontally
- Make sure that in order to warrant a sufficient cooling there will be a clearance of minimum 20 cm between the vacuum pump and nearby walls
- Make sure that no heat sensitive parts (plastics, wood, cardboard, paper, electronics) will touch the surface of the vacuum pump
- Make sure that the installation space or location is vented such that a sufficient cooling of the vacuum pump is warranted



CAUTION

During Operation the surface of the vacuum pump may reach temperatures of more than 70°C.

Risk of burns!

- Make sure that the vacuum pump will not be touched inadvertently during operation, provide a guard if appropriate
- Make sure that the sight glass (m, 83) will remain easily accessible

If the oil change is meant to be performed on location:

- Make sure that the drain port (n, 95), the oil filter (h, 100) and the filling port (l, 88) will remain easily accessible
- Make sure that enough space will remain for the removal and the reinsertion of the exhaust filter (p, 120)

Suction Connection



CAUTION

Intruding foreign objects or liquids can destroy the vacuum pump.

In case the inlet gas can contain dust or other foreign solid particles:

- Make sure that a suitable filter (5 micron or less) is installed upstream the vacuum pump
- Make sure that the suction line fits to the suction connection (d, 260) of the vacuum pump
- Make sure that the gas will be sucked through a vacuum-tight flexible hose or a pipe

In case of using a pipe:

- Make sure that the pipe will cause no stress on the vacuum pump's connection, if necessary use an expansion joint
- Make sure that the line size of the suction line over the entire length is at least as large as the suction connection (d, 260) of the vacuum pump

In case of very long suction lines it is prudent to use larger line sizes in order to avoid a loss of efficiency. Seek advice from your Schmalz representative!

If two or more vacuum pumps work on the same suction line, if the volume of the vacuum system is large enough to suck back oil or if the vacuum shall be maintained after switching off the vacuum pump:

- Provide a manual or automatic operated valve (= non-return valve) in the suction line

(the standard non-return valve that is installed inside the suction connection is not meant to be used for this purpose!)

If the vacuum pump is planned to be used for the suction of gas that contains limited quantities of condensable vapour:

- Provide a shut-off valve, a drip-leg and a drain cock in the suction line, so that condensates can be drained from the suction line
- Make sure that the suction line does not contain foreign objects, e.g. welding scales

Gas Discharge

The discharged gas must flow without obstruction. It is not permitted to shut off or throttle the discharge line or to use it as a pressurised air source.

The following guidelines for the discharge line do not apply, if the aspirated air is discharged to the environment right at the vacuum pump.



CAUTION

The discharged gas contains small quantities of vacuum oil.

Staying in vacuum oil contaminated air bears a risk of damage to health.

If air is discharged into rooms where persons stay, sufficient ventilation must be provided for.

- Make sure that the discharge line fits to the gas discharge (c, 155) of the vacuum pump

In case of using a pipe:

- Make sure that the pipe will cause no stress on the vacuum pump's connection, if necessary use an expansion joint
- Make sure that the line size of the discharge line over the entire length is at least as large as the gas discharge (c, 155) of the vacuum pump

In case the length of the discharge line exceeds 2 m it is prudent to use larger line sizes in order to avoid a loss of efficiency and an overload of the vacuum pump. Seek advice from your Schmalz representative!

With unrestricted suction the counter pressure at the gas discharge (c. 155) of the vacuum pump must not exceed 1.3 bar abs (in case of doubt to be verified during commissioning at a suitable time).

- Make sure that the discharge line either slopes away from the vacuum pump or provide a liquid separator or a drip leg with a drain cock, so that no liquids can back up into the vacuum pump



WARNING

Discharge lines made from non-conductive material can build up static charge.

Static discharge can cause explosion of potentially existing oil mist.

Discharge line must be made of conductive material or provisions must be made against static discharge.

Electrical Connection / Controls

- Make sure that the stipulations acc. to the EMC-Directive 2004/108/EC and Low-Voltage-Directive 2006/95/EC as well as the EN-standards, electrical and occupational safety directives, the local or national regulations, respectively, are complied with (this is the responsibility of the designer of the machinery into which the vacuum pump is to be incorporated; → page 24: note in the EC-Declaration of Conformity).
- Make sure that the power supply for the drive motor is compatible with the data on the nameplate of the drive motor (400)
- Make sure that an overload protection according to EN 60204-1 is provided for the drive motor
- Make sure that the drive of the vacuum pump will not be affected by electric or electromagnetic disturbance from the mains; if necessary seek advice from the Schmalz service

In case of mobile installation:

- Provide the electrical connection with grommets that serve as strain-relief

Installation

Mounting

- Make sure that the installation prerequisites (→ page 6) are complied with
- Set down or mount the vacuum pump at its location

Connecting Electrically



WARNING

Risk of electrical shock, risk of damage to equipment.

Electrical installation work must only be executed by qualified personnel that knows and observes the following regulations:

- IEC-Report 664 or DIN VDE 0110, respectively
- IEC 364 or CENELEC HD 384 or DIN VDE 0100
- BGV A2 (VBG 4) or corresponding national accident prevention regulation.



CAUTION

The connection schemes given below are typical. Depending on the specific order or for certain markets deviating connection schemes may apply.


Risk of damage to the drive motor!

The inside of the terminal box shall be checked for drive motor connection instructions/schemes.


- Electrically connect the drive motor (400)
- Connect the protective earth conductor

Connection Scheme Three-Phase Motor


Delta connection (low voltage):




Star connection (high voltage):



Double star Connection, multi-voltage motor (low voltage):



Star Connection, multi-voltage motor (high voltage):



CAUTION

Operation in the wrong direction of rotation can destroy the vacuum pump in short time.

Prior to starting-up it must be made sure, that the vacuum pump is operated in the proper direction (clockwise rotating field).

Version with three-phase motor:

- Determine the intended direction of rotation with the arrow (a. 431) (stuck on or cast)
- "Bump" the drive motor (400)
- Watch the fan wheel of the drive motor (400) and determine the direction of rotation just before the fan wheel stops

If the rotation must be changed:

- Switch any two of the drive motor wires (three-phase motor)

Connecting Lines/Pipes

In case the suction line is equipped with a shut-off valve:

- Connect the suction line
- Connect the discharge line

Installation without discharge line:

- Make sure that the gas discharge (c, 155) is open
- Make sure that all provided covers, guards, hoods etc. are mounted
- Make sure that cooling air inlets and outlets are not covered or obstructed and that the cooling air flow is not affected adversely in any other way

Filling Oil

In case the vacuum pump was treated with conservation oil:

- Drain the remainders of conservation oil



CAUTION

The vacuum pump is shipped without oil.

Operation without oil will ruin the vacuum pump in short time.

Prior to commissioning it must be made positively sure that oil is filled in.

The vacuum pump is delivered without oil (oil specification → page 23: Oil).

- Keep approx. 1.0 litres oil acc. to the table Oil (_ page 23) ready

Note: The amount given in these operating instructions is a guide. The sight glass (m, 83) indicates the actual amount to be filled in.



CAUTION

Filling oil through the suction connection (d, 260) will result in breakage of the vanes (r, 22) and destruction of the vacuum pump.

Oil may be filled through the filling port (l, 88) only.



CAUTION

During operation the oil separator is filled with hot, pressurised oil mist.

Risk of injury from hot oil mist with open filling port.

Risk of injury if a loosely inserted filling plug (l, 88) is ejected.

Remove the filling plug (l, 88) only if the vacuum pump is stopped.

The vacuum pump must only be operated with the filling plug (l, 88) firmly inserted.

- Remove the filling plug (l, 88)
- Fill in approx. 1.0 litres of oil
- Make sure that the level is between the MIN and the MAX-markings of the sight glass (m, 83)
- Make sure that the seal ring (89) is inserted into the filling plug (l, 88) and undamaged, replace if necessary
- Firmly reinsert the filling plug (l, 88) together with the seal ring (89)

Note: Starting the vacuum pump with cold oil is made easier when at this very moment the suction line is neither closed nor covered with a rubber mat.

- Switch on the vacuum pump

In case the suction line is equipped with a shut-off valve:

- Close the shut-off valve

In case the suction line is not equipped with a shut-off valve:

- Cover the suction connection (d, 260) with a piece of rubber mat
- Let the vacuum pump run for a few minutes

- Shut down the vacuum pump and wait a few minutes
- Check that the level is between the MIN and the MAX-markings of the sight glass (m, 83)

In case the level has dropped below the MIN-marking:

- Top-up oil

In case the suction line is equipped with a shut-off valve:

- Open the shut-off valve

In case the suction line is not equipped with a shut-off valve:

- Remove the piece of rubber mat and connect the suction line

Recording of Operational Parameters

As soon as the vacuum pump is operated under normal operating conditions:

- Measure the drive motor current and record it as reference for future maintenance and troubleshooting work

Version with exhaust filter pressure gauge:

- Read the scale of the exhaust filter pressure gauge and record it as reference for future maintenance and troubleshooting work (→ page 11: Checks during Operation)

Operation Notes

Use



CAUTION

The vacuum pump is designed for operation under the conditions described below.

In case of disregard risk of damage or destruction of the vacuum pump and adjoining plant components!

Risk of injury!

The vacuum pump must only be operated under the conditions described below.

The vacuum pump is intended for

- the suction

of

- air and other dry, non-aggressive, non-toxic and non-explosive gases.

Conveying media with a lower or higher density than air leads to an increased thermal and/or mechanical load on the vacuum pump and is permissible only after prior consultation with Schmalz.

Permissible temperature range of the inlet gas: see "Oil", "Ambient temperature range"

In case the vacuum pump is equipped with a gas ballast (optional) water vapour within the gas flow can be tolerated within certain limits (→ page 9: Conveying Condensable Vapours). The conveyance of other vapours shall be agreed upon with Schmalz.

The vacuum pump is intended for the placement in a non-potentially explosive environment.

Version with float valve (j, 200) and oil return line:

The vacuum pump is thermally suitable for continuous operation (100 percent duty).

Version with oil return valve (f, 280):

The vacuum pump is thermally suitable for continuous operation (observe the notes with regard to the oil recirculation: → page 4: Oil Circulation; → page 9: Oil Return).

The vacuum pump is ultimate pressure proof.



CAUTION

During operation the surface of the vacuum pump may reach temperatures of more than 70°C.

Risk of burns!

The vacuum pump shall be protected against contact during operation, it shall cool down prior to a required contact or heat protection gloves shall be worn.



CAUTION

The gas conveyed by the vacuum pump contains remainders of oil.

Aspiration of process gas over extended periods can be harmful.

The room into which the process gas is discharged must be sufficiently vented.

- Make sure that all provided covers, guards, hoods etc. remain mounted
- Make sure that protective devices will not be disabled
- Make sure that cooling air inlets and outlets will not be covered or obstructed and that the cooling air flow will not be affected adversely in any other way
- Make sure that the installation prerequisites (→page 6: Installation Prerequisites) are complied with and will remain complied with, particularly that a sufficient cooling will be ensured

Oil Return

Only for version with oil return valve (f, 280):

During operation oil accumulates at the bottom of the upper chamber of the oil separator (o, 75), which cannot flow down into the bottom chamber, as long as the vacuum pump runs (for detailed description: →page 4: Oil Circulation).

At the latest after 10 hours of continuous operation, in case of high pressure difference between suction side and pressure side after a shorter period, the vacuum pump must be shut down for at least 15 minutes, so that the oil can run down from the upper chamber of the oil separator (o, 75) into the bottom chamber. **Note:**

This is a good time to check the temperature, the level and the colour of the oil.

Conveying Condensable Vapours



CAUTION

Residual condensates dilute the oil, deteriorate its lubricating properties and can cause a seizure of the rotor.

Apply a suitable operating method to make sure that no condensates remain in the vacuum pump.

In order to use the vacuum pump for the conveyance of condensable vapours, the vacuum pump must be equipped with a shut-off valve in the suction line and with a gas ballast.

Version with gas ballast with ball-valve:

- Make sure that the gas ballast valve is open and will remain open during operation
- Close the shut-off valve in the suction line
- Operate the vacuum pump with the suction line shut off for approx. half an hour, so that the operating temperature rises to approx. 75 °C

At process start:

- Open the shut-off valve in the suction line

At the process end:

© J.Schmalz GmbH
Aacher Str. 29
72293 Glatten
Tel.: +49 7443 2403-0
Fax: +49 7443 2403-199

- Close the shut-off valve in the suction line
- Operate the vacuum pump for another approx. half an hour

8. Maintenance



DANGER

In case the vacuum pump conveyed gas that was contaminated with foreign materials which are dangerous to health, harmful material can reside in filters.

Danger to health during inspection, cleaning or replacement of filters.

Danger to the environment.

Personal protective equipment must be worn during the handling of contaminated filters.

Contaminated filters are special waste and must be disposed of separately in compliance with applicable regulations.



CAUTION

During operation the surface of the vacuum pump may reach temperatures of more than 70°C.

Risk of burns!

- Prior to action that requires touching of the vacuum pump, let the vacuum pump cool down, however, if the oil is to be drained, for no more than 20 minutes (the oil shall still be warm when being drained)
- Prior to disconnecting connections make sure that the connected pipes/lines are vented to atmospheric pressure

8.1 Maintenance Schedule

Note: The maintenance intervals depend very much on the individual operating conditions. The intervals given below shall be considered as starting values which should be shortened or extended as appropriate. Particularly heavy duty operation, such like high dust loads in the environment or in the process gas, other contaminations or ingress of process material, can make it necessary to shorten the maintenance intervals significantly.

Daily: Check the level and the colour of the oil (→ page 10: Checking the Oil)

Weekly: Check the vacuum pump for oil leaks - in case of leaks have the vacuum pump repaired (Schmalz service)

Monthly: Check the function of the exhaust filter (p, 120) (→page 11: Exhaust Filter)
Make sure that the vacuum pump is shut down and locked against inadvertent start up
In case an inlet air filter is installed:
• Check the inlet air filter, if necessary replace
In case of operation in a dusty environment:
• Clean as described → page 9: Every 6 Months:

Every 6 Months: Make sure that the housing is free from dust and dirt, clean if necessary
Make sure that the vacuum pump is shut down and locked against inadvertent start up
Clean the fan cowings, fan wheels, the ventilation grilles and cooling fans

Every Year: Make sure that the vacuum pump is shut down and locked against inadvertent start up
Replace the exhaust filter (p, 120) (_ page 11: Exhaust Filter)

In case an inlet air filter is installed:
Replace the inlet air filter
Check the inlet screen (261), clean if necessary

Version with gas ballast (440) with sinter metal filter:
Clean the sinter metal filter (compressed air)

Every 500 - 2000 Operating Hours (→page 10: Oil Life):
Change the oil and the oil filter (h, 100) (→
page 10: Oil and Oil Filter Change)

Version with float valve (j, 200) and oil return line:
Check the float valve (j, 200) (→ page 11:
Checking the Float Valve)

Checking the Oil

Checking the Level

- Make sure that the vacuum pump is shut down and the oil has collected at the bottom of the oil separator (o, 75)
- Read the level on the sight glass (m, 83)

In case the level has dropped underneath the MIN-marking:

- Top up oil (→ page 10: Topping up Oil)

In case the level exceeds the MAX-marking:

- Excessive dilution with condensates - change the oil and check the process
- If appropriate retrofit a gas ballast (Schmalz Service) and observe the chapter Conveying Condensable Vapours (→ page 9)

In case the level exceeds the MAX-marking despite proper use of the gas ballast:

- Clean the sinter metal filter (compressed air)

Topping up Oil

Note: Under normal conditions there should be no need to top up oil during the recommended oil change intervals. A significant level drop indicates a malfunction (→ page 14: Troubleshooting).

Note: During operation the exhaust filter gets saturated with oil. It is therefore normal that the oil level will drop slightly after replacement of the exhaust filter.



CAUTION

Filling oil through the suction connection (d, 260) will result in breakage of the vanes (r, 22) and destruction of the vacuum pump.

Oil may be filled through the filling port (l, 88) only.



CAUTION

During operation the oil separator is filled with hot, pressurised oil mist.

Risk of injury from hot oil mist with open filling port.

Risk of injury if a loosely inserted filling plug (l, 88) is ejected.

Remove the filling plug (l, 88) only if the vacuum pump is stopped.

The vacuum pump must only be operated with the filling plug (l, 88) firmly inserted.

- Make sure that the vacuum pump is shut down and locked against inadvertent start up
- Remove the filling plug (l, 88)
- Top up oil until the level reaches the middle of the sight glass (m, 83)
- Make sure that the seal ring (89) is inserted into the filling plug (l,88) and undamaged, replace if necessary
- Firmly reinsert the filling plug (l, 88) together with the seal ring (89)

Checking the Colour of the Oil

Note: The oil should be light, either transparent, a little foamy or a little tarnished. A milky discolouration that does not vanish after sedation of the oil indicates contamination with foreign material. Oil that is either contaminated with foreign material or burnt must be changed (→ page 10: Oil and Oil Filter Change).

In case the oil appears to be contaminated with water or other condensates despite proper use of the gas ballast:

- Clean the sinter metal filter (compressed air)

Oil Life

The oil life depends very much on the operating conditions. A clean and dry air stream and operating temperatures below 100 °C are ideal.

Under these conditions the oil and the oil filter (h, 100) shall be changed every 500 to 2000 operating hours or after half a year.

Under very unfavourable operating conditions the oil life can be less than 500 operating hours. Extremely short life times indicate malfunctions (→ page 14: Troubleshooting) or unsuitable operating conditions, though.

Choosing a synthetic oil instead of a mineral oil can extend the oil life. To select the oil best suited oil for your process please contact your Schmalz representative.

If there is no experience available with regard to the oil life under the prevailing operation conditions, it is recommended to have an oil analysis carried out every 500 operating hours and establish the change interval accordingly.

Oil and Oil Filter Change



Danger

In case the vacuum pump conveyed gas that was contaminated with harmful foreign material the oil and the oil filter will be contaminated with harmful material.

Danger to health during the changing of contaminated oil and oil filters.

Danger to the environment.

Wear personal protective equipment during the changing of contaminated oil and oil filters.

Contaminated oil and oil filters are special waste and must be disposed of separately in compliance with applicable regulations.

Draining Used Oil

Note: After switching off the vacuum pump at normal operating temperature wait no more than 20 minutes before the oil is drained (the oil shall still be warm when being drained).

- Make sure that the vacuum pump is shut down and locked against inadvertent start up
- Make sure that the vacuum pump is vented to atmospheric pressure
- Put a drain tray underneath the drain port (n, 95)
- Remove the drain plug (n, 95) and drain the oil

When the oil stream dwindles:

- Reinsert the drain plug (n, 95)
- Switch the vacuum pump on for a few seconds
- Make sure that the vacuum pump is shut down and locked against inadvertent start up
- Remove the drain plug (n, 95) again and drain the remaining oil
- Make sure that the seal ring (96) is inserted into the drain plug (n, 95) and undamaged, replace if necessary
- Firmly reinsert the drain plug (n, 95) together with the seal ring (96)
- Dispose of the used oil in compliance with applicable regulations

Flushing the Vacuum Pump



Warning

Degraded oil can choke pipes and coolers.

Risk of damage to the vacuum pump due to insufficient lubrication.

Risk of explosion due to overheating.

If there is a suspicion that deposits have gathered inside the vacuum pump shall be flushed.

- Make sure that all the used oil is drained
- Make sure that the used oil filter (h, 100) is still in place
- Create 1.0 litres flushing agent from 50 percent oil and 50 percent paraffin or diesel fuel/fuel oil
- Make sure that the drain plug (n, 95) is firmly inserted
- Remove the filling plug (l, 88)
- Fill in the flushing agent
- Firmly reinsert the filling plug (l, 88)
- Close the suction line
- Run the vacuum pump for at least half an hour
- Drain the flushing agent and dispose of it in compliance with applicable regulations

Note: Due to the use of paraffin and even more in case of using diesel fuel/fuel oil, an unpleasant odour can occur after recommissioning. If this is a problem, diesel fuel/fuel oil should be avoided and the vacuum pump be run at idle in a suitable place until the unpleasant odour vanishes.

Checking the Float Valve

(version with float valve and oil return line only)

Note:

It is essential that the float valve (j, 200) works properly, so that the vacuum pump will achieve the intended ultimate pressure and no oil will be expelled out of the gas discharge (c, 155).

- Make sure that the vacuum pump is shut down and locked against inadvertent start up
- Prior to disconnecting pipes/lines make sure that the connected pipes/lines are vented to atmospheric pressure
- Remove the discharge line, if necessary
- Remove the exhaust cover (c, 155)
- Remove the oil from the floater chamber with the aid of a suction hose or a wash bottle
- Undo the screws (341) and remove the fan cover (e, 340)

Note: While undoing the banjo fitting of the oil return line (j, 195) a small amount of oil will leak out: keep a cleaning rag ready. Be careful not to lose the sealing rings of the banjo fitting.

- Undo the banjo fitting of the oil return line (j, 195) from the oil separator (o, 75) and bend the oil return line a little bit aside
- Undo the two screws of the flange of the float valve (j, 200) and pull the float valve out of the oil separator (o, 75)

- Check the cleanliness and function of the float valve (j, 200), blow out with compressed air, if necessary
- Make sure that the o-ring on the flange of the float valve (j, 200) is in place and undamaged, replace with a new o-ring, if necessary
- Insert the float valve (j, 200) in the proper orientation into the oil separator (o, 75) and fasten it with two screws and lock washers
- Connect the banjo fitting of the oil return line (j, 195) to the oil separator (o, 75) with the hollow-core screw and two seal rings
- Fasten the fan cover (e, 340) to the vacuum pump with the screws (341)

Only if the exhaust filter (p, 120) is not meant to be changed, too:

- Make sure that the seal (141) under the exhaust cover (c, 155) is clean and undamaged, if necessary replace with a new seal (141)
- Mount the exhaust cover (c, 155) together with the seal (141), hex head screws (146) and lock washers on the oil separator (o, 75)
- If necessary connect the discharge line

Replacing the Oil Filter

- Make sure that the oil is drained
- Remove the oil filter (h, 100)
- Apply a drop of fresh oil on the seal ring of the new oil filter (h, 100)
- Mount the new oil filter (h, 100) and tighten it by hand
- Dispose of the used oil filter in compliance with applicable regulations

Filling in Fresh Oil

- Keep 1.0 litres oil acc. to the table Oil (➔ page 23) ready

Note: The amount given in these operating instructions is a guide. The sight glass (m, 83) indicates the actual amount to be filled in.

- Make sure that the drain plug (n, 95) is firmly inserted



CAUTION

Filling oil through the suction connection (d, 260) will result in breakage of the vanes (r, 22) and destruction of the vacuum pump.

Oil may be filled through the filling port (l, 88) only.

- Remove the filling plug (l, 88)
- Fill in approx. 1.0 litres of oil
- Make sure that the level is between the MIN and the MAX-markings of the sight glass (m, 83)
- Make sure that the seal ring (89) is inserted into the filling plug (l, 88) and undamaged, replace if necessary
- Firmly reinsert the filling plug (l, 88) together with the seal ring (89)

Exhaust Filter

Checks during Operation

Schmalz recommends the use of a filter pressure gauge (available as accessory, ➔ page 21: Accessories). Without filter pressure gauge the filter resistance shall be assessed on the basis of the drive motor current drawn.

Version with exhaust filter pressure gauge:

- Remove the suction line from the suction connection (d, 260) (unrestricted suction!)
- Make sure that the vacuum pump is running
- Check that the reading on the filter pressure gauge is in the green field

- Reconnect the suction line to the suction connection (d, 260)

Version without filter pressure gauge:

- Make sure that the vacuum pump is running
- Check that the drive motor current drawn is in the usual range Version with oil return valve (f, 280)

Note: The discharged gas will also contain oil if the vacuum pump is operated without interruption for too long a period (➔ page 8: Operation Notes).

- Check that the discharged gas is free from oil

Assessment

If

the reading on the filter pressure gauge is in the red field,

or

the drive motor draws too much current and/or the pump flow rate has dropped,

then the exhaust filter (p, 120) is clogged and must be replaced.

Note: Exhaust filters cannot be cleaned successfully. Clogged exhaust filters must be replaced with new ones.

If the filter pressure gauge indicates a lower pressure than usual,

or

the drive motor draws less current than usual,

then the exhaust filter (p, 120) is broken through and must be replaced.

If the discharged gas contains oil, the exhaust filter (p, 120) can either be clogged or broken through and, if applicable, must be replaced.

Change of the Exhaust Filter



In case the vacuum pump conveyed gas that was contaminated with harmful foreign material, the exhaust filter will be contaminated with harmful Material.

Danger to health during the changing of the contaminated exhaust filter.

Danger to the environment.

Wear personal protective equipment during the changing of the contaminated exhaust filter.

Used exhaust filters are special waste and must be disposed of separately in compliance with applicable regulations.



The filter spring (125) can fly out of the exhaust port during removal of insertion.

Risk of eye injury.

Eye protection goggles must be worn while handling filter springs (125).

Removing the Exhaust Filter

- Make sure that the vacuum pump is shut down and locked against inadvertent start up
 - Prior to disconnecting pipes/lines make sure that the connected pipes/lines are vented to atmospheric pressure

- Remove the discharge line, if necessary
- Remove the exhaust cover (c, 155) from the oil separator (o, 75)
- Loosen the screw in the centre of the exhaust filter retaining spring (125), but do not remove it at this time
- Press the exhaust filter retaining spring (125) out of the indent and rotate it
- Remove the exhaust filter retaining spring (125) from the oil separator (o, 75)
- Pull the exhaust filter (p, 120) out of the oil separator (o, 75)

Inserting the Exhaust Filter



The non-OEM spares market offers exhaust filters that are geometrically compatible with Schmalz-vacuum pumps, but do not feature the high retention capacity of genuine Schmalz-exhaust filters and deteriorate the service life and the efficiency of the vacuum pumps due their increased back pressure.

Increased risk of damage to health.

Adverse effect on efficiency and service life.

In order to keep the emission on the lowest possible level and to preserve efficiency and service life only genuine Schmalz-exhaust filters shall be used.

- Make sure that the new exhaust filter (p, 120) is equipped with a new o-ring
- Insert the exhaust filter (p, 120) such that its port is properly seated in its receptacle in the oil separator (n, 75)
- Make sure that the tip of the screw in the centre of the exhaust filter retaining spring (125) protrudes the retaining spring by about 2 - 5 revolutions
- Insert the exhaust filter retaining spring (125) such that its ends are secured in their receptacles in the oil separator (o, 75) by the protrusions and that the tip of the screw snaps into the indent of the exhaust filter (p, 120)
- Tighten the screw in the exhaust filter retaining spring (125) such that the screw head touches the spring steel sheet
- Make sure that the seal (141) under the exhaust cover (c, 155) is clean and undamaged, if necessary replace with a new seal (141)
- Mount the exhaust cover (c, 155) together with the seal (141), hex head screws (146) and lock washers on the oil separator (o, 75)
- If necessary connect the discharge line

Note: During operation the exhaust filter gets saturated with oil. It is therefore normal that the oil level will drop slightly after replacement of the exhaust filter.

9. Overhaul



In order to achieve best efficiency and a long life the vacuum pump was assembled with precisely defined tolerances.

This adjustment will be lost during dismantling of the vacuum pump..

It is therefor strictly recommended that any dismantling of the vacuum pump that is beyond of what is described in this manual shall be done be Schmalz service.



DANGER

In case the vacuum pump conveyed gas that was contaminated with harmful foreign material the oil, the oil filter and the exhaust filter(s) will be contaminated with harmful material.

Harmful material can reside in pores, gaps and internal spaces of the vacuum pump.

Danger to health during dismantling of the vacuum pump.

Danger to the environment.

Prior to shipping the vacuum pump shall be decontaminated as good as possible and the contamination status shall be stated in a „Declaration of Contamination“.

Schmalz service will only accept vacuum pumps that come with a completely filled in and legally binding signed "Declaration of Contamination"

10. Removal from Service

Temporary Removal from Service

Prior to disconnecting pipes/lines make sure that all pipes/lines are vented to atmospheric pressure

Recommissioning



CAUTION

Vanes (r, 22) can stick after a long period of standstill.

Risk of vane breakage if the vacuum pump is started with the drive motor.

After longer periods of standstill the vacuum pump shall be turned by hand.

After longer periods of standstill:

- Make sure that the vacuum pump is locked against inadvertent start up
- Remove the cover around the fan of the drive motor (400)
- Slowly rotate the fan wheel by hand several revolutions in the intended direction of rotation (see stuck on or cast arrow (a, 431))
- Mount the cover around the fan wheel of the drive motor (400)

If deposits could have gathered in the vacuum pump:

- Flush the vacuum pump (➔ page 9: Maintenance)
- Observe the chapter Installation and Commissioning (➔ page 6)

Dismantling and Disposal



DANGER

In case the vacuum pump conveyed gas that was contaminated with harmful foreign material the oil, the oil filter and the exhaust filter(s) will be contaminated with harmful material.

Harmful material can reside in pores, gaps and internal spaces of the vacuum pump.

Danger to health during dismantling of the vacuum pump.

Danger to the environment

During dismantling of the vacuum pump personal protective equipment must be worn.

The vacuum pump must be decontaminated prior to disposal.

Oil, oil filters and exhaust filters must be disposed of separately in compliance with applicable regulations.



CAUTION

Used oil, used exhaust filters and used oil filters are special waste and must be disposed of in compliance with applicable regulations.



CAUTION

The filter spring (125) can fly out of the exhaust port during removal of insertion.

Risk of eye injury.

Eye protection goggles must be worn while handling filter springs (125).

- Remove the exhaust filter (p, 120) (_ page 11: Exhaust Filter)
- Drain the oil
- Remove the oil filter (h, 100)
- Make sure that materials and components to be treated as special waste have been separated from the vacuum pump
- Make sure that the vacuum pump is not contaminated with harmful foreign material

According to the best knowledge at the time of printing of this manual the materials used for the manufacture of the vacuum pump involve no risk.

- Dispose of the used oil in compliance with applicable regulations
- Dispose of special waste in compliance with applicable regulations
- Dispose of the vacuum pump as scrap metal

11. Troubleshooting



WARNING

Risk of electrical shock, risk of damage to equipment.

Electrical installation work must only be executed by qualified personnel that knows and observes the following regulations:

- IEC 364 or CENELEC HD 384 or DIN VDE 0100 respectively
- IEC-Report 664 or DIN VDE 0110
- BGV A2 (VBG 4) or equivalent national accident prevention regulation.



CAUTION

During the Operation the surface of the vacuum pump may reach temperatures of more than 70°C.

Risk of burns!

Let the vacuum pump cool down prior to a required contact or wear heat protection gloves.

Problem	Possible Cause	Remedy
<p>The vacuum pump does not reach the usual pressure</p> <p>The drive motor draws a too high current (compare with initial value after commission- ing)</p> <p>Evacuation of the system takes too long</p>	The vacuum system or suction line is not leak-tight	Check the hose or pipe connections for possible leak
	In case a vacuum relief valve/regulating system is installed: The vacuum relief valve/regulating system is misadjusted or defective	Adjust, repair or replace, respectively
	Contaminated oil (the most common cause)	Change the oil(➔ page 9: Maintenance)
	No or not enough oil in the reservoir	Top up oil (➔ page 9: Maintenance)
	The exhaust filter (p, 120) is partially clogged	Replace the exhaust filter (p, 120) (➔ page 9: Maintenance)
	The oil filter (h, 100) is clogged (the oil flows through the bypass only, the oil does not get filtered any more)	Replace the oil filter (h, 100) (➔ page 9: Maintenance)
	The screen (261) in the suction connection (d,260) is partially clogged	Clean the screen (261) If cleaning is required too frequently install a filter upstream
	In case a filter is installed on the suction connection (d, 260): The filter on the suction connection (d, 260) is partially clogged	Clean or replace the inlet air filter, respectively
	Partial clogging in the suction, discharge or pressure line	Remove the clogging
	Long suction, discharge or pressure line with too small diameter	Use larger diameter
	The valve disk of the inlet non-return valve is stuck in closed or partially open position	Disassemble the inlet, clean the screen (261) and the valve (257) as required and reassemble
	The oil tubing is defective or leaking The oil return line (j, 195) is broken	Tighten the connections Replace the connections and/or the tubing (replace with identically dimensioned parts only)


	Version with float valve (j, 200) and oil return line The float valve (j, 200) is stuck in open position	Make the float valve (j, 200) movable, replace if necessary (➔ page 11: Checking the Float Valve)
	A shaft seal is leaking	Replace the shaft seal ring (Schmalz service)
	An/The exhaust valve (q, 159) is not properly seated or stuck in partially open position	Disassemble and reassemble the exhaust valve(s) (q, 159) (Schmalz service)
	A vane (r, 22) is blocked in the rotor or otherwise damaged	Free the vanes (r, 22) or replace with new ones (Schmalz service)
	The radial clearance between the rotor (s, 14) and the cylinder (t, 1) is no longer adequate	Readjust the vacuum pump (Schmalz service)
	Internal parts are worn or damaged	Repair the vacuum pump (Schmalz service)
The gas conveyed by the vacuum pump smells displeasing	Process components evaporating under vacuum Readily volatile and thus gaseous components of the oil, e.g. additives, particularly right after an oil change. Note: This is no indication of a malfunction of the oil separator. The oil separator is able to retain droplets of oil, however no gaseous components of it.	Check the process, if applicable Use a different type of oil, if applicable
The vacuum pump does not start	The drive motor (400) is not supplied with the correct voltage or is overloaded	Supply the drive motor (400) with the correct voltage
	The drive motor starter overload protection is too small or trip level is too low	Compare the trip level of the drive motor starter overload protection with the data on the nameplate, correct if necessary In case of high ambient temperature: set the trip level of the drive motor starter overload protection 5 percent above the nominal drive motor current
	One of the fuses has blown	Check the fuses
	Version with alternating current motor: The drive motor capacitor is defective	Repair the drive (Schmalz service)
	The connection cable is too small or too long causing a voltage drop at the vacuum pump	Use sufficiently dimensioned cable
	The vacuum pump or the drive motor is blocked	Make sure the drive motor is disconnected from the power supply Remove the fan cover Try to turn the drive motor with the vacuum pump by hand If the unit is still frozen: remove the drive motor and check the drive motor and the vacuum pump separately If the vacuum pump is blocked: Repair the vacuum pump (Schmalz service)
	The drive motor (400) is defective	Replace the drive motor (Schmalz service)
The vacuum pump is blocked	Solid foreign matter has entered the vacuum pump	Repair the vacuum pump (Schmalz service) Make sure the suction line is equipped with a screen If necessary additionally provide a filter
	Corrosion in the vacuum pump from remaining condensate	Repair the vacuum pump (Schmalz service) Check the process Observe the chapter Conveying Condensable Vapours (➔ page 9)

	Version with three-phase motor: The vacuum pump was run in the wrong direction	Repair the vacuum pump (Schmalz service) When connecting the vacuum pump make sure the vacuum pump will run in the correct direction (➔ page 7: Installation)
	After shutting down the vacuum pump the vacuum system exerted under pressure onto the pump chamber which sucked back excessive oil from the oil separator into the pump chamber When the vacuum pump was restarted too much oil was enclosed between the vanes (r,22) Oil could not be compressed and thus broke a vane (r, 22)	Repair the vacuum pump (Schmalz service) Make sure the vacuum system will not exert Under pressure onto the shut-down vacuum pump, if necessary provide an additional shut-off valve or non-return valve
	After shutting down the vacuum pump condensate ran into the pump chamber When the vacuum pump was restarted too much condensate was enclosed between the vanes (r, 22) Condensate could not be compressed and thus broke a vane (r, 22)	Repair the vacuum pump (Schmalz service) Make sure no condensate will enter the vacuum pump, if necessary provide a drip leg and a drain cock Drain condensate regularly
The drive motor is running, but the vacuum pump stands still	The coupling (310) between the drive motor and the vacuum pump is defective	Replace the coupling element (310)
The vacuum pump starts, but labours or runs noisily or rattles The drive motor draws a too high current (compare with initial value after commissioning)	Loose connection(s) in the drive motor terminal box Version with three-phase-motor: Not all drive motor coils are properly connected The drive motor operates on two phases only	Check the proper connection of the wires against the connection diagram (particularly on motors with six coils) Tighten or replace loose connections
	Version with three-phase motor: The vacuum pump runs in the wrong direction	Verification and rectification ➔ page 6: Installation and Commissioning
	Standstill over several weeks or months	Let the vacuum pump run warm with inlet closed
	Oil viscosity is too high for the ambient temperature	Use synthetic oil, if necessary use oil of the next lower viscosity class (CAUTION: operation with too low viscosity can cause chatter marks inside the cylinder) Warm up the oil with a heater prior to starting up the vacuum pump, or run the vacuum pump in intervals in order not to let it get too cold
	Improper oil quantity, unsuitable oil type	Use the proper quantity of one of the recommended oils (➔ page 23: Oil change: ➔ page 9: Maintenance)
	No oil change over extended period of time	Perform oil change incl. flushing and oil filter replacement (➔ page 9: Maintenance)
	The exhaust filter (p, 120) is clogged and appears black from burnt oil	Flush the vacuum pump Replace the oil filter (h, 100) Replace the exhaust filter (p, 120) Fill in new oil (➔ page 9: Maintenance) In case the oil life is too short: use oil with better heat resistance (➔ page 23: Oil) or retrofit cooling
	Foreign objects in the vacuum pump Broken vanes (r, 22) Stuck bearings	Repair the vacuum pump (Schmalz service)

The vacuum pump runs very noisily	Defective bearings	Repair the vacuum pump (Schmalz service)
	Worn coupling element (310)	Replace the coupling element (310)
	Stuck vanes (r, 22)	Repair the vacuum pump (Schmalz service) Use only recommended oils (➔ page 23: Oil) and change more frequently
The vacuum pump runs very hot (the oil sump temperature shall not exceed 100 °C)	Insufficient air ventilation	Make sure that the cooling of the vacuum pump is not impeded by dust/dirt Clean the fan cowlings, the fan wheels, the ventilation grilles and the cooling fins Install the vacuum pump in a narrow space only if sufficient ventilation is ensured On a vacuum pump with oil-cooler: clean the intermediate spaces of the finned tube
	Ambient temperature too high	Observe the permitted ambient temperatures
	Temperature of the inlet gas too high	Observe the permitted temperatures for the inlet gas
	The exhaust filter (p, 120) is partially clogged	Replace the exhaust filter (p, 120)
	The oil filter (h, 100) is clogged (the oil flows through the bypass only, the oil does not get filtered any more)	Replace the oil filter (h, 100) (➔ page 9: Maintenance)
	Not enough oil in the reservoir	Top up oil
	Oil burnt from overheating	Flush the vacuum pump Replace the oil filter (h, 100) Replace the exhaust filter (p, 120) Fill in new oil (➔ page 9: Maintenance) In case the oil life is too short: use oil with better heat resistance (➔ page 23: Oil) or retrofit cooling
	Mains frequency or voltage outside tolerance range	Provide a more stable power supply
	Partial clogging of filters or screens Partial clogging in the suction, discharge or pressure line	Remove the clogging
	Long suction, discharge or pressure line with too small diameter	Use larger diameter
The vacuum pump fumes or expels oil drop- lets through the gas discharge The oil level drops	The exhaust filter (p, 120) is not properly seated	Check the proper position of the exhaust filter (p, 120), if necessary insert properly (➔ page 9: Maintenance)
	The o-ring is missing or damaged	Add or replace resp. the o-ring (➔ page 9: Maintenance)
	The exhaust filter (p, 120) shows cracks	Replace the exhaust filter (p, 120) (➔ page 9: Maintenance)
	The exhaust filter (p, 120) is clogged with foreign matter Note: The saturation of the exhaust filter with oil is no fault and does not impair the function of the exhaust filter! Oil dropping down from the exhaust filter is returned to the oil circulation.	Replace the exhaust filter (p, 120) (➔ page 9: Maintenance)
	Version with oil return valve (f, 280): In case the vacuum pump runs for more than 10 hours without interruption, oil can collect in the upper chamber of the oil separator (o, 75) to an extent that it gets expelled together with the discharged gas	Regularly shut down the vacuum pump for short periods of time. Check that the oil return valve (f, 280) functions properly and lets oil run from the upper into the bottom chamber of the oil separator (o, 75) as soon as the vacuum pump is shut down (➔ page 4: Oil Circulation)

	Version with oil return valve (f, 280): The oil return valve (f, 280) does not work properly or is clogged (proper function is when blowing into the valve it should close, when vacuum is applied, the valve should open; CAUTION: do not let your mouth get in direct contact with the oil return valve, do not inhale through the oil return valve!)	Clean or replace the oil return valve (f, 280)
	Version with float valve (j, 200) and oil return line: The float valve (j, 200) is stuck in closed position	Make the float valve (j, 200) movable, replace if necessary (➔ page 11: Checking the Float Valve)
	The oil return line (j, 195) is clogged or broken	Clean a clogged oil return line (j, 195) Replace a broken oil return line (j, 195) with an identically dimensioned line, top up oil (if necessary by Schmalz service)
The oil is black	Oil change intervals are too long The oil was overheated	Flush the vacuum pump Replace the oil filter (h, 100) Replace the exhaust filter (p, 120) Fill in new oil (➔ page 9: Maintenance) In case the oil life is too short: use oil with better heat resistance (➔ page 23: Oil) or retrofit cooling
The oil is watery and coloured white	The vacuum pump aspirated water or significant amounts of humidity Version with gas ballast: The filter of the gas ballast is clogged	Flush the vacuum pump Replace the oil filter (h, 100) Replace the exhaust filter (p, 120) Fill in new oil (➔ page 9: Maintenance) Modify the operational mode (➔ page 9: Operating Notes ➔ Conveying Condensable Vapours) Version with gas ballast (440) with sinter metal filter: Clean the sinter metal filter (compressed air)
The oil is resinous and/or sticky	Improper oil type, perhaps in confusion Topping up of incompatible oil	Flush the vacuum pump Replace the oil filter (h, 100) Replace the exhaust filter (p, 120) Fill in new oil (➔ page 9: Maintenance) Make sure the proper oil is used for changing and topping up
The oil foams	Mixing of incompatible oils	Flush the vacuum pump Replace the oil filter (h, 100) Replace the exhaust filter (p, 120) Fill in new oil (➔ page 9: Maintenance) Make sure the proper oil is used for topping up

12. Exploded View



XX*
 Nur Ausführung mit Ölrücklaufventil
 Version with oil return valve only
 Seulément version avec soupape de retour d'huile
 Solo modelo con válvula de retorno de aceite
 Somente versão com válvula de retorno de óleo
 Alleen versie met olieterugzuigventiel
Kun version med olieåterfølgventil
 Bare version med oljerestkuleringsventil
Veza pozice sa zpajnim olejovym ventilom

XX**
 Nur Ausführung mit Schwimmerventil und Ölrückföhrleitung
 Version with float valve and oil return line only
 Seulément version avec soupape à flotteur et conduite de retour
 Solo modelo con válvula de flotador y línea de retorno de aceite
 Somente versão com bóia e linha de retorno de óleo
 Alleen versie met vlotteklep en olieåterfølgleiding
Kun version med svømmerventil og olieåterfølgventil
 Bare version med flottørværdi og oljerestkuleringsventil
Veza pozice s pivlakovym ventilom a zpajnim olejovym vedenim

13. Spare Parts

Note: When ordering spare parts or accessories acc. to the table below please always quote the type („Type“) and the serial no. („No“) of the vacuum pump this will allow Schmalz service to check if the vacuum pump is compatible with a modified or improved part.

The exclusive use of genuine spare parts and consumables is a prerequisite for the proper function of the vacuum pump and for the granting of warranty, guarantee or goodwill.

This parts list applies to a typical configuration of the vacuum pump EVE-OG-25 F / ...40 F. Depending on the specific order deviating parts data may apply.

Your point of contact for service and spare parts/ Ihr Ansprechpartner für Service und Ersatzteile in Deutschland:

J. Schmalz GmbH
Aacher Str. 29
72293 Glatten
Tel: +49 7443 2403-0
Fax: +49 7443 2403-199

Find the list of Schmalz companies all over the world (by the time of the publication of these installation and operating instructions) on ➔ page 24 (rear cover side).

Find the up-to-date list of Schmalz companies and agencies all over the world on the internet at www.schmalz.com

Pos	Part	Qty	Part no.
1	Cylinder (EVE-OG-25 F)	1	0223 139 799
1	Cylinder (EVE-OG-40 F)	1	0223 137 410
14	Rotor with shaft sleeves (EVE-OG-25 F)	1	0950 138 501
14	Rotor with shaft sleeves (EVE-OG-40 F)	1	0950 138 493
18	Shaft sleeves	2	0472 105 823
24	Cylindercover A-Site, complete	1	0952 138 010
27	Cylindercover B-Site, complete	1	0952 138 011
30	Needle bearing	2	0473 103 122
35	Shaft seal ring	2	0487 000 005
42	Supporting washer	2	0391 000 016
43	Hex head screw	4	0410 000 023
46	Seal ring	1	0484 000 029
47	Plug	1	0415 000 002
50	O-ring	2	0486 000 537
53	Hex head screw	6	0410 000 126
57	Parallel pin	1	0437 138 870
60	Taper pin	4	0437 000 070
65	Parallel key	1	0434 000 019
66	Parallel key	1	0434 000 019
75	Oil separator (Version with float valve and oil return line)	1	0266 137 346
75	Oil separator (Version with oil return valve)	1	0266 138 692
83	Sight glass	1	0583 000 001

84	Gasket	1	0480 000 271
88	Plug	1	0710 000 009
89	O-ring	1	0486 000 590
95	Plug	1	0710 000 010
96	O-ring	1	0486 000 505
99	Nipple	1	0461 000 061
100	Oilfilter	1	0531 000 002
105	Cover	1	0320 109 603
106	Gasket	1	0480 000 153
107	Hex head screw	4	0410 000 017
125	Filter spring	1	0947 000 720
136	Round gasket-service cover	1	0486 114 368
138	Hex head screw	4	0410 000 029
139	Service cover	1	0247 113 773
141	Gasket	1	0480 000 112
146	Hex head screw	4	0410 000 021
155	Exhaust cover plate, complete	1	0947 125 296
159	Exhaust valve, complete	2	0916 126 769
185	Gasket	1	0480 000 150
186	Stud bolt	4	0412 104 730
191	Hex nut	4	0420 000 035
195	Oil return line, complete	1	0946 138 688
200	Float valve, complete	1	0947 138 417
210	Oil supply (EVE-OG-25 F) complete	1	0913 140 895
210	Oil supply (EVE-OG-40 F) complete	1	0913 142 101
250	Inlet flange, lower part	1	0246 101 999
255	O-ring	2	0486 000 526
257	Valve insert, complete	1	0916 143 238
260	Inlet flange	1	0246 000 541
261	Screen	1	0534 000 018
265	Hex head screw	4	0410 105 417
280	Oil return valve, complete	1	0946 139 037
300	Motor flange	1	0247 107 490
301	Hex head screw	3	0410 000 126
310	Coupling, complete, for 3phase motor, motor shaftØ 19mm	1	0510 000 006
310	Coupling, complete, for 3phase motor, motor shaftØ 24mm	1	0510 000 008
310	Coupling for other motors	1	on request
312	Coupling sleeve for AC-motors	1	0512 000 003
315	Protection clip	3	0710 109 012
321	Axial flow fan (EVE-OG-25 F)	1	0524 120 370
321	Axial flow fan (EVE-OG-40 F)	1	0524 108 652
326	Locking ring	1	0432 000 367
340	Fan cover	1	0713 000 653
341	Tapping screw	2	0416 120 665
345	Protective grid	1	0713 110 795

391	Eye bolt	1	0416 000 001
400	3phase motor 0,75kW, 230/400V, 50Hz, 1500min ⁻¹ , shaft-Ø 19mm	1	0612 000 918
400	3phase motor 1,1kW, 230/400V, 50Hz, 1500min ⁻¹ , shaft-Ø 24mm	1	0614 127 186
400	other motors	1	on request
401	Hex head screw	2	0410 000 122
411	Hex head screw	2	0410 000 126
412	Foot	1	0391 107 504
415	Hex head screw	1	0410 000 122
421	Rubber foot	1	0561 000 001
422	Rubber foot	2	0561 000 030
425	Washer	1	0431 000 132
431	Directional arrow	1	0565 000 003
432	Label „Before Installation“	1	0565 104 694
434	Label „Hot Surface“	1	0565 531 032
440	Gas ballast (optional)	1	0916 142 105
440	Gas ballast adjustable (optional)	1	0916 142 106
540	Air filter with paper cartridge (not shown, optional) (EVE-OG-25 F)	1	10.07.01.00007
540	Air filter with paper cartridge (not shown, optional) (EVE-OG-40 F)	1	10.07.01.00008
--	Paper cartridge for air filter (not shown, optional) (EVE-OG-25 F)		10.07.01.00017
--	Paper cartridge for air filter (not shown, optional) (EVE-OG-40 F)		10.07.01.00018

14. Spare Parts Kits

Spare parts kit	Description	Part No.
Service kit (EVE-OG-25 F) (EVE-OG-40 F)	Oil filter, exhaust filter and pertinent seals	10.03.02.00060
Overhaul kit (EVE-OG-25 F)	service kit, set of seals and all overhaul parts, except for the float valve	0993 143 209
Overhaul kit (EVE-OG-40 F)	service kit, set of seals and all overhaul parts, except for the float valve	0993 143 318

15. Accessories

Zubehör	Beschreibung	Teilenr.
Filter pressure gauge	for easy checking off he degree of clogging of the exhaust filter	10.07.02.00050
Gas ballast complete	for the conveying of condensable vapours, with sinter metal filter	0916 142 105
Gas ballast, adjustable, complete	for the conveying of condensable vapours, with sinter metal filter and ball valve	0916 142 106
Motor safety switch	adjustment range 2,4 – 4,0A, 3 Ph.	10.04.04.00120

16. Oil

Bezeichnung / Denomination	OEL-EVE- ANDEROL 555
ISO-VG	100
Basis / Base	Synthetischer Diester / synthetic Diester
Dichte / Density [g/cm ³]	0,960
Umgebungstemperaturbereich / Ambient temperature range [°C]	-20 bis 210
Kinematische Viskosität bei 40°C / Kinematic viscosity at 40°C [mm ² /s]	96,64
Kinematische Viskosität bei 100°C / Kinematic viscosity at 100°C [mm ² /s]	10,54
Flammpunkt / Flashpoint [°C]	250
Pourpoint [°C]	-36
Teilenr / Part no. 1 l – Gebinde / 1 l – packaging	27.02.01.00055
Teilenr / Part no. 5 l – Gebinde / 5 l – packaging	27.02.01.00056
Anmerkung	Breiter Temperaturanwendungsbereich, Verlängerte Ölwechselintervalle Wide temperature application range, Extended oil change intervals

17. EC-Declaration of Conformity

DE EG-Konformitätserklärung
EN EC- Declaration of Conformity



Hersteller / Manufacturer

J. Schmalz GmbH, Aacher-Str. 29, D - 72293 Glatten

Produktbezeichnung / Product name

Vakuumpumpen Serien / Vacuum Pumps series

EVE-OG 10 / 16
EVE-OG 25 / 40
EVE-OG 63 / 100
EVE-OG 165 / 255

Erfüllte einschlägige EG-Richtlinien / Applicable EC directives met

- 2006/42/EG Maschinenrichtlinie / Machinery Directive / Directive sur les machines / Directiva para máquinas / Direttiva macchine / Machinerichtlijn
- 2004/108/EG Elektromagnetische Verträglichkeit / Electromagnetic Compatibility
- 2006/95/EG Elektrische Betriebsmittel zur Verwendung innerhalb bestimmter Spannungsgrenzen / Electrical Equipment Designed for Use within Certain Voltage Limits

Angewendete harmonisierte Normen / Harmonised standards applied

- EN ISO 12100 Sicherheit von Maschinen - Allgemeine Gestaltungsleitsätze - Risikobeurteilung und Risikominderung / Safety of Machinery - General principles for design - Risk assessment and risk reduction
- EN ISO 13857 Sicherheit von Maschinen - Sicherheitsabstände gegen das Erreichen von Gefährdungsbereichen mit den oberen und unteren Gliedmaßen / Safety of Machinery - Safety distances to prevent hazard zones being reached by the upper and lower limbs
- EN 1012-1 Kompressoren und Vakuumpumpen - Sicherheitsanforderungen - Teil 1 und 2 / Compressors and vacuum pumps - Safety requirements - Part 1 and 2
- EN ISO 2151 Akustik- Kompressoren und Vakuumpumpen, Bestimmung der Geräuschemission / Acoustics - Noise test code for compressors and vacuum pumps
- EN 60204-1 Sicherheit von Maschinen - Elektrische Ausrüstung von Maschinen / Safety of Machinery - Electrical equipment of machines
- EN 61000-6-1 Elektromagnetische Verträglichkeit - Störfestigkeit / Electromagnetic Compatibility - Immunity
- EN 61000-6-2 Elektromagnetische Verträglichkeit - Störfestigkeit / Electromagnetic Compatibility - Immunity
- EN 61000-6-3 Elektromagnetische Verträglichkeit - Störaussendung / Electromagnetic Compatibility - Emission
- EN 61000-6-4 Elektromagnetische Verträglichkeit - Störaussendung / Electromagnetic Compatibility - Emission

Nationale Normen / National standards

- EN ISO 2151 Akustik- Kompressoren und Vakuumpumpen, Bestimmung der Geräuschemission - Verfahren der Genauigkeitsklasse 2 / Acoustics - Noise test code for compressors and vacuum pumps - Engineering method (grade 2)

Dokumentationsverantwortlicher / Person responsible for documentation

Klaus-Dieter Fanta / J. Schmalz GmbH, Aacher-Str. 29, D - 72293 Glatten

Unterschrift, Angaben zum Unterzeichner / Signature, details of signatory

Glatten, 09.11.2012

Wolfgang Schmalz
Geschäftsführer / Managing Director

CE_EVE-OG_10_16_25_40_63_100_165_205_255_305_DE-EN
Status 11.2012
Page 1/1

J. Schmalz GmbH
Förder- u. Handhabungstechnik
Aacher Straße 29, D 72293 Glatten
Tel.: +49(0)7443/2403-0
Fax.: +49(0)7443/2403-256

info@schmalz.de
www.schmalz.com



18. Schmalz world wide

Local competence with own subsidiaries

<p>Brazil Tel. +55 4130720738 Fax +55 4130720739 schmalz@schmalz.com.br</p> <p>Canada Tel. +1 905 569 9520 Fax +1 905 569 8256 schmalz@schmalz.ca</p> <p>China Tel. +86 21 5109 9933 Fax +86 21 5039 8882 schmalz@schmalz.net.cn</p> <p>Finland Tel. +358 9 85746 92 Fax +358 9 85746 94 schmalz@schmalz.fi</p> <p>France Tel. +33 (0) 1 6473 1730 Fax +33 (0) 1 6006 6371 schmalz@schmalz.fr</p> <p>India Tel. +91 (0) 20 4072 5500 Fax +91 (0) 20 4072 5588 schmalz@schmalz.co.in</p>	<p>Italy Tel.+39 0321 621510 Fax+39 0321 621714 schmalz@schmalz.it</p> <p>Japan Tel.+81 45 308 9940 Fax+81 45 308 9941 schmalz@schmalz.co.jp</p> <p>Netherlands Tel.+31 (0)74 255 5757 Fax+31 (0)74 255 5758 schmalz@schmalz.nl</p> <p>Poland Tel.+48 (0)22 46 04970 Fax+48 (0)22 87 40062 schmalz@schmalz.pl</p> <p>Russia Tel.+7 495 9671248 Fax+7 495 9671249 schmalz@schmalz.ru</p> <p>Spain Tel. +34 94 4805585 Fax +34 94 4807264 schmalz@schmalz.es</p>	<p>South Korea Tel. +82 31 8162403 Fax +82 31 8162404 schmalz@schmalz.co.kr</p> <p>Switzerland Tel. +41 44 88875 25 Fax +41 44 88875 29 schmalz@schmalz.ch</p> <p>Turkey Tel. +90 216 3400121 Fax +90 216 3400124 schmalz@schmalz.com.tr</p> <p>USA Tel. +1 919 7130880 Fax +1 919 7130883 schmalz@schmalz.us</p>
---	--	---