
#### LAMP

# AZ-GD400-HL STAINLESS STEEL SOFT CLOSING FLAP LID SYSTEM Installation instructions

Thank you for selecting our product. Before starting installation, please read this manual thoroughly to ensure correct installation. Please keep this manual at hand for future reference.

# **ABOUT THE PRODUCT**

- Damper allows silent closing of lid.
- Side plates for anti-pinch function.



## FOR YOUR SAFE WORK AND CORRECT INSTALLATION

### Meaning of symbols









**Caution** If not followed injury or damage may result.

- The product is designed to function when installed vertically as shown below. Horizontal, slanted or upside down installation will result in improper function and may lead to injury.
- To prevent the risk of the product falling and causing injury, ensure that the lid body is securely fastened to a structure with adequate strength.
- O Do not disassemble nor modify any parts other than those described in this document.
- Recommended ambient temperature range is 0 to 40 degrees centigrade.
- The closing speed of the lid may vary according to ambient temperature .If the product is stored below zero degrees, please store in room temperature for several hours before use.

#### **PARTS DESCRIPTION**

Description	Quantity
Flap lid body	1
Warning sticker	1
Cover cap	4

#### TOOLS NEEDED FOR INSTALLATION


Screws (not provided)


Choose the suitable length according to the material to be mounted.

Recommended screw: 3mm tapping screw · · · · · 4 pcs

#### **DIMENSION DRAWING**

# CUTOUT DIMENSIONS







#### **INSTALLATION PROCEDURE**




Make sure that the LAMP logo is at the top.



Do not leave any gap between the flap lid body and the mounting surface.




- [1] Having opened the lid, insert the screws through the provided access screw holes (two on each side) and fasten the flap lid body securely.
- [2] Make sure that the final assembly is securely fastened.



Slowly open and close the lid completely a few times in order to ensure correct operation.

5

Cover the access holes with the cover caps provided.



Paste the warning sticker in a visible position to avoid any injury when operating the lid.



SUGATSUNE KOGYO CO.,LTD

SUGATSUNE KOGYO (UK) LTD

SUGATSUNE EUROPE GmbH Düsseldorf, GERMANY

Phone: +49 211 53812900 E-mail:sales@sugatsune.eu ISO9001(Japan Offices and Sugatsune America) and ISO14001(Chiba Production division and Logistics center), certified.

E-mail:lamp@sugatsune.com.cn

Phone: +91 22 28314490/91 E-mail:sales@sugatsune.in

Guangzhou, CHINA

Phone: +86 20 6639 3552 E-mail:lamp@sugatsune.com.cn SUGATSUNE AMERICA, INC

2019.04 1283-2

SUGATSUNE KOGYO INDIA PRIVATE LIMITED Mumbai, INDIA

SUGATSUNE CANADA, INC.

Phone: +1 514 312 5267 E-mail:support@sugatsune.ca