



Roller cages

for guide rails



Dimensioning formula:

$$\text{number of rollers in cage} = \frac{\text{length of guide rail} - \frac{1}{2} \text{ travel}}{\text{division T}}$$



Material:

Cage plastic.

Rollers tool steel 1.2842

Sample order:

nIm 21052-02010 include number of rollers in cage (010 = 10 rollers).

Dimensioning formula see right.

Order No.	D	No. of rollers	B	H	T (division)	Load F N/roller
21052-02***	2	2-200	0,5	4,5	4	60
21052-03***	3	2-200	1	7,5	5	100
21052-06***	6	2-200	2,4	15	9	400