


# **R4-EM** 9 Series Electromechanical Rotary Lock

Concealed cam Electronic access with internal motor control






6-9

12V

24V

- Minimal power draw
  - Integrated connector
  - Extended housing for added security
  - Door and Trigger Sensor
  - Microswitch to detect latch status
  - Mechanical over-ride with integrated cable bracket
  - 12V to 24V operations
  - Efficient DC gear motor actuation
  - Detent mechanism for pull-open function
  - Simple two-hole installation



Other options available. For complete details on variety, part numbers, installation and specification, go to


INFO CLIC

www.southco.com/R4-EM

### Installation

Panel Preparation

Base Mounting Style	Recommended minimum mounting hole		
1/4-20 thread	Ø 7.2 (.283)		
M6 thread	Ø 6.9 (.272)		
Thru hole	Ø 7.6 (.300)		



# Operation

See page 34 for operating instructions

### Accessories

Striker Bolt or Cast Striker See page 35







See page 35



CONNECT - CREATE - INNOVAT

# **Material & Finish**

Top Housing: PC/ABS or Aluminum Bottom Housing: PC/ABS or Zinc, Die Cast Pivot Pins: Steel, zinc plated Cam, Trigger: Steel, sealed Springs: Stainless steel passivated Trigger Interlock Lever: Glass-filled nylon Bistable Spring Retainer: Zinc Alloy Drive Cam: Acetal, black Output Cam: Acetal, white **Electrical Specifications** 

**Recommended Operating Voltage:** 12 to 24 VDC

Typical Operating Current : 12 V Models: Less than 500mA

# Latch Connector

**Pin Assignment** PIN 1: Ground (-) PIN 2: Power (+) **PIN 3: Control Signal** PIN 4: Latch Status PIN 5: None

PIN 6: Door status

Other options available. For complete details on variety, part numbers, installation and specification, go to



<u>8-</u>9

12V

24V





# **R4-EM** Electronic Rotary Latch

Operating instructions

**Operation** - Auto relock

- The signal unlocks the R4-EM latch and releases the spring loaded cam which rotates out to push a lightweight door open. The mechanism will cycle through unlatched then relatched state automatically, regardless of input signal on time.
- 2. Push door closed to engage striker after unlock time has expired. Striker will rotate cam to closed position.









## **Operation -** Delayed relock

- The signal unlocks the R4-EM latch leaving a biased closed door in the closed position. The unlock time is controlled by the access control device.
- 2. Manually pull door/striker free from R4-EM latch.
- 3. Manually push door closed. Striker will rotate cam to closed position, however latch will remain unlocked and can be re-opened as long as signal is present.
- 4. After accessing the door, the signal can be removed to re-lock the R4-EM. This can be done with the door in the open or closed position.

Other options available. For complete details on variety, part numbers, installation and specification, go to

INFO CLIC


ww.southco.com/R4-EM

# **R4-EM** Electronic Rotary Latch Strikers - Cable mounting kits




#### 

Cast Striker with Door Sensor Part number R4-90-804-10\*




**Striker Bolt - Small** 



### Material and Finish

Striker bolts: Steel, zinc plated Cast strikers: Zinc alloy Cable mounting kits: Glass-filled nylon, black \*Note: Latch and striker installation details can be found on the latch trade drawing at www.southco.com.

Cast Striker without Door Sensor Part number R4-90-800-10\*





55.7

(2.19)

#### **Cable Mounting Kit**

Part number R4-EM-52 – Rivets included Part number R4-EM-72 – Screws included





			Т							
	Striker Bolt		Cast Striker		Cable Mounting Kit					
	R4-90-121-XX	R4-90-511-20	R4-90-800-10	R4-90-804-10	R4-EM-52	R4-EM-72	R4-EM-87	R4-EM-952		
R4-EM-9	~		~	~				~		
R4-EM-8	~		~	~						
R4-EM-5 & 7	~		~		~		~			
<b></b>		~				~				
R4-EM-1 & 2	~		~		~		~			



